

DVR Recordings will be removed from your DVR Library after 180 days.

To keep a program from being deleted, follow these simple steps to

### Protect a Recorded Program.

**Option 1** - Using the **List** button to access DVR recordings

#### Step 1

Press the **STB** button on your remote control.

#### Step 2


Press the **List** button on your remote control to access the programs on your TV that are saved in your DVR library.

#### Step 3

Use the **up/down arrows** on the remote control to highlight the program you want to protect, and then press the **green button** to open the **Actions** menu.

#### Step 4

In the **Actions** menu, use the **down arrow** on the remote control to scroll down to highlight **Protect**, then press **OK** on the remote control. Once you press "OK," the program you highlighted will now show a **blue and white shield** next to the title of the program that you just protected.



**Option 2** - Using the **Menu** button to access DVR recordings

**Step 1**



Press the **STB** button on your remote control.

**Step 2**

Press the **Menu** button on your remote control. Use the **down arrow** to highlight **Recordings** then use the **right arrow** to highlight **Current**. Then press **OK** on your remote control to access the programs on your TV that are saved in your DVR library.

**Step 3**

Use the **up/down arrows** on the remote control to highlight the program you want to protect.



**Step 4**

Once your program is highlighted, press the **green button** to open the **Actions** menu.

**Step 5**

In the **Actions** menu, use the **down arrow** on the remote control to scroll down to highlight **Protect**, then press **OK** on the remote control. Once you press "OK," the program you highlighted will now show a **blue and white shield** next to the title of the program that you just protected.

